

Parts of a cabinet door

1. Arch

The arch is at the top of the door. As you notice in the picture the “arch” on this door is straight. We offer 7 different arches.

2. Inside profile

This is how the inside edge of the door will look. We offer 11 different inside profiles.

3. Panel

The panel is the middle of the door. There are 15 different center panels to choose from.

4. Outside Profile

The outside profile is how the outside edge of the door is going to look. We offer 14 different outside profiles.

5. Crown

It is not part of the door itself but is a nice way to “finish” the look of your cabinetry. Crown is optional. We have several different types of crown available.



Another door option available is to have a flat door. This is a modern look.

